



OUR MOUNTING BRACKETS ARE DESIGNED TO EASE THE PROCESS OF ALIGNING A FULL-EXTENSION DRAWER SLIDE TO THE DRAWER BOX ONCE THE SLIDE HAS BEEN MOUNTED INTO THE CABINET. BRACKETS ARE DESIGNED TO WORK WITH BOTH FACE FRAME AND FRAMELESS CABINETS.

To use with face frame cabinets:

1.

Install full-extension drawer slides with our Magnetic Drawer Slide Mounting Tool (NZ03). This will position the slide 1/4" off the bottom of the face frame.



2.

Place the brackets into the drawer box opening so that the support tabs of the brackets rest on the top of the face frame rail and under the slide as shown. Clamp the bracket to the face frame to hold it in position.



3.

Pull out the slides on both sides of the cabinet so they are approximately 10" from the front of the face frame.



4.

Position the drawer box in the opening so it balances on the brackets. Position the end of the slide so that it sets back approximately 1/8" from the face of the drawer box



5.

Start a screw at the endpoint of the slide. Continue to add screws and then pull the drawer box out further to finish the process. Remove brackets and you have perfect drawer box alignment!



For frameless cabinets, reverse the brackets end for end and swap sides so the long toe points inward as shown. Move the brackets into position so that they contact the base of the slides. Clamp into place as shown and continue mounting the drawer box as described in the framed cabinet example above,

