

- Slide dustport into slots of mounting blocks.
  - 2. Position on L Fence were desired
- 3. Mark outside edge of blocks
- 4. Measure in 3/8" from outside edge
- 5. Drill 1/8" hole on front edge and bottom edge of L fence for each side, countersink holes on face sides
- 6. Use 1" # 8 screws & fasten blocks to fence
- 7. Be sure that the dust port slides freely.