

# Wet Filter Installation Instructions



## Step 1.

Remove the Motor assembly from the top of the vac. Next, lift out the dry cloth filter from the vac base.

## Step 2.

Loosen the plastic knob on the bottom of the cartridge filter and slide the cartridge filter off of the motor intake assembly.



## Step 3.

Slide the Foam "wet" filter onto the vac intake as shown here. Make sure the filter covers the entire intake assembly.

## Step 4.

Place the motor unit back onto the vac and you are ready to use the Summit Vac for cleaning up wet or damp debris.

