### **#PKTYCXXX**

# **Tycoon Closed End Pen Kit**

### **Kit Features:**


- Blind End Design
- · Minimum parts easy to assemble
- · Available in multiple finishes
- Overall Length: 6" closed
- Uses Rollerball to fill Fountain Pen Pump

### **Included Accessories:**

- Bladder hose for 10.5mm item # PKMBLT105
- Bladder hose for 12.5mm item # PKMBLT125
- 10.5mm End bushing, item # PKMBL105
- 12.5mm End bushing, item # PKMBL125
- 10.5mm counter sink bushing, item # PKMBLCBU

### **Other Required Accessories:**

- Big Grabber pen mandrel system, item #PKMBLB2
- 10.5mm drill bit item, # PK105MM
- 12.5mm drill bit item # PKPLI-DB
- Bushing set, item # PKTYCEBU (2/set)
- Barrel trimmer sleeves, item # PKMAJJRBTS
- (use with 7mm trimmer)(2/set)
- 10MM drill bit, item # PK10-10
- 7mm drill bit # PK-7MM
- · 2 part Epoxy or insta-cure, Cayanoacrylate glue C/A
- · Project requires 2 pen blanks Total length 7.5"



#### **#PKTYCXXX PSI Woodworking Products Diagram D - Upper Barrel** Sizing Washer or Bushing\* Upper Step Bushing Hose Bladder Upper End Wood Removed Mandrel Shaft Cap Blank **Bushing** MT Taper Mount Lock Nut Long Tightening Nut Cap Insert Mandrel Collet **Finished Barrel** Live Center Upper Blank Cap Connector

### Turning the Upper Barrel and Cap see Diagram D

• Slide the upper step bushing and bladder over the mandrel shaft.

• Thread on the upper end bushing.

• Slide upper blank over the hose bladder onto the upper step bushing.

• Affix the sizing washer over the threads. Screw the cap blank over the washer.

• Tighten the 2 nuts and expand the bladder to secure the set up. Insert the mandrel into the spindle of the lathe, bring the tail stock in for support. Lock in place.

• Turn the blanks down to the bushings\*. When near the sizing bushing\* stop and remove the bushing. Continue the process and make a smooth transition to match both blanks. When near finishing the profile at the tip end, remove the tailstock and part the wood

(see Diagram D) finish the end manually. Sand and finish the upper barrel.

### Turning the Lower Barrel see Diagram E


• Insert the lower step bushing, the bladder and screw the 10.5mm end bushing over the mandrel shaft.

• Slide the blank over, to bottom. Expand bladder with lock nuts.

• Attach the mandrel into the taper of the lathe. Bring the tailstock over so the live center support the blank. Lock set up in place, ready for turning.

• Turn the blank down to the bushing at the front. Measure 3-5/8" as the end of the barrel and shape the end round as shown. Part off then sand off the end and finish the barrel manually.

## Diagram E - Lower Barrel



### **Upper Barrel Assembly see Diagram F**

• Remove the sizing washer

• Affix the clip over the exposed thread. Screw the cap end down onto the cap connector.

• Press the band into the opposite end of the upper barrel.

### Lower Barrel Assembly see Diagram F

• Press the nib coupler, recessed end first into the opening at the lower barrel.

### FOR ROLLER BALL REFILL:

• Insert (thread) the spring into the recess in the bottom of the refill. Drop the refill into the opening at the lower barrel.

• Screw the tip over the refill.


### FOR FOUNTAIN PEN:

• Affix either the ink cartridge or fountain pen pump into the back of the nib assembly. The cartridge will supply the ink. The refillable pump will require an ink bottle to draw ink into the storage pump.

### **GENERAL**

• Just screw on both ends of the pen when not in use. Note: Cap will *NOT* post

### **Diagram F Assembly**



© 2015 PSI Woodworking Philadelphia PA 19115 - v11/15